

## Torque testers

### 7750 Display unit

- registered design
- for displaying the actual torque as measured
- units of measurement: N·m, ft·lb, in·lb
- modes of operation: track, peak hold, first peak (only with manual operation)
- additional display of actual torque applied with clicking torque wrenches
- swivels to any desired position thanks to universal ball-joint



Code	⊘ g
<b>52 1000 50</b>	182

### 7760 Mains adaptor

- Input: 110 V-230 V AC
- Output: 9 V DC, with interchangeable socket adaptors



Code	⊘ g
<b>52 1100 56</b>	201

### 7761 Interface adaptor

- required for automated calibration and adjustment of angle-controlled torque wrenches No 714 using calibrating and adjusting units perfectControl® No 7794-2 and 7794-3



Code	⊘ g
<b>52 1100 61</b>	26

### 7761/3 Interface adaptor set

- Contents:
- No 7761 interface adaptor
  - No 7752 spiral cable
  - No 7760 mains adaptor



Code	⊘ g
<b>96 52 11 61</b>	255

### 7311/7312 Plastic box, empty

- for safe storage and transport of transducers (please order inlays separately)



Code	No	for transducer	⊘ g
<b>81 5000 03</b>	<b>7311</b>	7721; 7722; 7723; 7728 1-20	554
<b>81 5000 04</b>	<b>7312</b>	7724-1; 7728 40-100	1346

### 7313/7314 Inlays for plastic box

Code	No	for transducer	⊘ g
<b>8307 10 30</b>	<b>7313</b>	7721; 7722; 7723; 7728 1-20	77
<b>8307 10 31</b>	<b>7314</b>	7724-1; 7728 40-100	242

### 409M Adaptor


- 1/4" socket x 3/8" plug (6.3 x 10)



code	L mm	∅ mm	⊘ g
<b>110300 10</b>	13	28	14

### 7787 Square drive adaptor

- 1/4" socket x 3/4" plug (6.3 x 20)



Code	L mm	∅ mm	⊘ g
<b>58 52 10 87</b>	15.5	29	41

### 7788 Square drive adaptor

- 3/8" socket x 3/4" plug (10 x 20)



Code	L mm	∅ mm	⊘ g
<b>58 52 10 88</b>	23.5	29	50